

Thank you for your purchase, please feel free to contact us for customer support at 1-800-343-9463

Fusion Straight Peg Installation Guide



Package Contents:

Qty	Item Description
18	Straight Pegs
4	#8 Wood Screws
4	Drywall Anchors
1	Backer Panel
1	Faceplate

Recommended Installation Tools: (Not Included)

Tape Measure
Level
1/8" Drill Bit
Electrical Drill
Stud Finder

Recommended Fastener Applications:

Drywall Anchors (Included) - Use for installing rails to drywall if studs are not present in the desired location. Do not use drywall anchors to secure into a

Wood Screws (Included) - Use wood screw to secure rails to wall studs or wood panels, do not use on drywall without securing to a stud. Concrete or Masonry applications not recommended.

Concrete, Brick or Stucco (Not Included) - 3/16" x 1-1/4" Masonry Screw or #8x1-1/4" screw with the proper concrete anchors.



Important! Before Installing Fusion Panel do the following:



- 1 Check the Package Contents for missing or damaged items

Contact Customer Service at 1-800-611-8644 for questions or concerns

Step 1 Use Stud Finder to map mounting location

Step 2 Place Backer Panel against wall in desired location

Step 3 Use Level and 1/8" Drill-bit to mark mounting holes

Step 4 Drill Anchor into wall and then mount Backer Panel with wood screw, otherwise directly secure the panel into stud with wood screw.

Step 5 If applicable, remove Faceplate's protective film

Step 6 Line up Faceplate and Backer Panel holes and secure Faceplate using pegs.

Step 7 Congratulation you have completed your Fusion Wine Rack Installation!

